



¹ Allow a minimum of 1/16" gap between the back of the screw and the head of screw flange. Screw should penetrate a minimum of 1" into solid backing.

² Trusscore Wall&CeilingBoard installed horizontally.

NOTES:

- Trusscore Wall&CeilingBoard can be installed with any readily available wood (corrosion-resistant) screws with a minimum head diameter of 3/8".
- Depending on your wall assembly, we recommend different types of screws. For steel studs, use self-tapping #10 x 1-1/4" truss or pancake head screws. Stainless steel screws are only required for highly corrosive or moist environments.
- We recommend using one screw per two square feet of space when installing Trusscore Wall&CeilingBoard

trusscore
material + science

SCALE: 1-1/2" = 1'-0"

REVISION DATE: 2024-02-21

DRAWING: G4

FLOOR TO WALL, WALL TO CEILING - ROUNDED CORNER
2X4,6,8,10... STEEL STUD
HORIZONTAL PANEL INSTALLATION