



1 Trusscore Wall&CeilingBoard installed horizontally

2 Outside Corner Square trim is intended to be adhered to Wall&CeilingBoard with a one-part, neutral cure silicone sealant.

NOTES:

- Trusscore Wall&CeilingBoard can be installed with any readily available wood (corrosion-resistant) screws with a minimum head diameter of 3/8".
- Depending on your wall assembly, we recommend different types of screws. For steel studs, use self-tapping #10 x 1-1/4" truss or pancake head screws. Stainless steel screws are only required for highly corrosive or moist environments.
- We recommend using one screw per two square feet of space when installing Trusscore Wall&CeilingBoard



SCALE: 2" = 1'-0"

REVISION DATE: 2024-02-21

DRAWING: I2

OUTSIDE CORNER DETAIL - ROUNDED & SQUARE CORNERS
 2x4,6,8,10... STEEL STUD
 HORIZONTAL PANEL INSTALLATION