



<sup>1</sup> Allow a minimum of  $\frac{1}{16}$ " gap between the back of the screw and the head of screw flange. Screw should penetrate a minimum of 1" into solid backing.

<sup>2</sup> Trusscore Wall&CeilingBoard installed vertically.

**NOTES:**

- Trusscore Wall&CeilingBoard can be installed with any readily available wood (corrosion-resistant) screws with a minimum head diameter of 3/8".
- Depending on your wall assembly, we recommend different types of screws. For a concrete wall assembly, use 3/16" x 1-1/4" Flathead head screws. Stainless steel screws are only required for highly corrosive or moist environments.
- We recommend using one screw per two square feet of space when installing Trusscore Wall&CeilingBoard



SCALE: 1-1/2" = 1'-0"

REVISION DATE: 2023-03-20

DRAWING: B7

## FLOOR TO WALL, WALL TO CEILING

### 8" CONCRETE MASONRY UNIT (CMU)