



#10 x 1-1/4" TRUSS OR PANCAKE HEAD SCREW<sup>1</sup>

16" TRUSSCORE WALL&CEILINGBOARD<sup>2</sup> - TC16XX

2X6 STEEL STUD

INSIDE COVE CORNER - TCT12IC10

BATT INSULATION

1/2" J-TRIM - TCT12J10

#10 x 1-1/4" TRUSS OR PANCAKE HEAD SCREW<sup>1</sup>

FINISHED FLOOR

SUB-FLOOR

<sup>1</sup> Allow a minimum of 1/16" gap between the back of the screw and the head of screw flange. Screw should penetrate a minimum of 1" into solid backing.

<sup>2</sup> Trusscore Wall&CeilingBoard installed horizontally.

NOTES:

- Trusscore Wall&CeilingBoard can be installed with any readily available wood (corrosion-resistant) screws with a minimum head diameter of 3/8".
- Depending on your wall assembly, we recommend different types of screws. Depending on your wall assembly, we recommend different types of screws. For steel studs, use self-tapping #10 x 1-1/4" truss or pancake head screws. Stainless steel screws are only required for highly corrosive or moist environments.
- We recommend using one screw per two square feet of space when installing Trusscore Wall&CeilingBoard



SCALE: 1-1/2" = 1'-0"
REVISION DATE: 2023-04-25
DRAWING: F5

FLOOR TO WALL, WALL TO CEILING  
2X6 STEEL STUD WITH INSULATION