



#10 x 1-1/4" TRUSS OR PANCAKE HEAD SCREW¹

16" TRUSSCORE WALL&CEILINGBOARD²
- TC16XX

2X6 STEEL STUD

INSIDE COVE CORNER - TCT12IC10

BATT INSULATION

1/2" J-TRIM - TCT12J10

#10 x 1-1/4" TRUSS OR PANCAKE HEAD SCREW¹

FINISHED FLOOR

SUB-FLOOR

¹ Allow a minimum of 1/16" gap between the back of the screw and the head of screw flange. Screw should penetrate a minimum of 1" into solid backing.

² Trusscore Wall&CeilingBoard installed horizontally.

- NOTES:
- Trusscore Wall&CeilingBoard can be installed with any readily available wood (corrosion-resistant) screws with a minimum head diameter of 3/8".
 - Depending on your wall assembly, we recommend different types of screws. For steel studs, use self-tapping #10 x 1-1/4" truss or pancake head screws. Stainless steel screws are only required for highly corrosive or moist environments.
 - We recommend using one screw per two square feet of space when installing Trusscore Wall&CeilingBoard



SCALE: 1-1/2" = 1'-0"
REVISION DATE: 2024-02-21
DRAWING: G5

FLOOR TO WALL, WALL TO CEILING - ROUNDED CORNER
2X4,6,8,10... STEEL STUD INSULATION
HORIZONTAL PANEL INSTALLATION